

BOX-GUIDE RUNNING GUIDELINES

- Check clearances inside of power-tongs
 - No impact shall be made between power tongs and guided coupling.
 - ° Tongs' mass combined with localized impact can damage the plastic.
- Do not hit, hammer, or drop Box-Guide™ couplings.
 Damage may occur.
- Always follow rod manufacturer's torque cards and procedures for proper make-up. Box-Guides work at standard torque displacement values.

SIZES AVAILABLE:

3/4" Rod x 2-3/8" Tubing 3/4" Rod x 2-7/8" Tubing 7/8" Rod x 2-3/8" Tubing 7/8" Rod x 2-7/8" Tubing 1" Rod x 2-7/8" Tubing

 Always check the inner diameter (ID) of your tubing or equipment to ensure RFG Box-Guides will fit properly. Box-Guides for 2-3/8" have a maximum outer diameter (OD) of 1.890 inches and Box-Guides for 2-7/8" tubing have a maximum OD of 2.347 inches.

